

Agilent R422C mm-Wave Planar-Doped Barrier Detector

Data Sheet



26.5 to 40.0 GHz

Outstanding Performance

The Planar-Doped Barrier (PDB) diode technology combines the best characteristics of point-contact and low barrier Schottky to provide exceptional performance. This PDB diode technology provides detectors with broadband flatness, excellent square-law response, and low SWR.

These specifications along with the rugged design of the detector make it an excellent value.

Agilent R422C Specifications

Frequency Range: 26.5 to 40 GHz Frequency Response: ±0.6 dB SWR: 1.78 Low Level Sensitivity: 0.42 mV/µW Maximum Operating Input: 100 mW Typical Short-Term Maximum Input (less than one minute): 1 watt **Video Impedance:** 0.5 to 5 k Ω (nominal 1.5 k Ω) Noise (peak to peak with CW power applied to produce 100 mV output, 400 kHz BW): <50 µV **Output Polarity** (Standard): Negative **Environmental Capabilities** Operating Temperature: -65°C to +100°C Temperature Cycling: MIL-STD-883, Method 1010.1 (-65°C to +100°C) **Output Connector:** BNC (female) Equivalent Flange: UG-599/U, MIL-F-3922/54-003 Fits Waveguide Size: EIA WR-28, MIL-W-85/3-006



Agilent Technologies' Test and Measurement Support, Services, and Assistance

Agilent Technologies aims to maximize the value you receive, while minimizing your risk and problems. We strive to ensure that you get the test and measurement capabilities you paid for and obtain the support you need. Our extensive support resources and services can help you choose the right Agilent products for your applications and apply them successfully. Every instrument and system we sell has a global warranty. Support is available for at least five years beyond the production life of the product. Two concepts underlie Agilent's overall support policy: "Our Promise" and "Your Advantage."

Our Promise

Our Promise means your Agilent test and measurement equipment will meet its advertised performance and functionality. When you are choosing new equipment, we will help you with product information, including realistic performance specifications and practical recommendations from experienced test engineers. When you receive your new Agilent equipment, we can help verify that it works properly and help with initial product operation.

Your Advantage

Your Advantage means that Agilent offers a wide range of additional expert test and measurement services, which you can purchase according to your unique technical and business needs. Solve problems efficiently and gain a competitive edge by contracting with us for calibration, extra-cost upgrades, out-of-warranty repairs, and onsite education and training, as well as design, system integration, project management, and other professional engineering services. Experienced Agilent engineers and technicians worldwide can help you maximize your productivity, optimize the return on investment of your Agilent instruments and systems, and obtain dependable measurement accuracy for the life of those products.



www.agilent.com/find/emailupdates

Get the latest information on the products and applications you select.

Agilent T&M Software and Connectivity

Agilent's Test and Measurement software and connectivity products, solutions and developer network allows you to take time out of connecting your instruments to your computer with tools based on PC standards, so you can focus on your tasks, not on your connections. Visit **www.agilent.com/find/connectivity** for more information.

For more information on Agilent Technologies' products, applications or services, please contact your local Agilent office. The complete list is available at:

www.agilent.com/find/contactus

Korea: (tel) (080) 769 0800 (fax) (080)769 0900 Latin America: (tel) (305) 269 7500 Taiwan: (tel) 0800 047 866 (fax) 0800 286 331 Other Asia Pacific Countries: (tel) (65) 6375 8100 (fax) (65) 6755 0042 Email: tm_ap@agilent.com

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2004 Printed in USA, August 4, 2004 5965-2880E

